





APPENDIX C

Complex Group Lockout Procedure and Permit -

The following lock-out and permit sequence will be used to ensure that the machinery, equipment, or powered mobile equipment is stopped, isolated from all energy sources, and locked out before workers perform any service or maintenance. Procedures must be certified by a professional engineer.

1. **IDENTIFY OPERATOR IN CHARGE (OIC) AND QUALIFIED UTILITY EMPLOYEE IN CHARGE (QUEIC).** Where the OIC has been identified as responsible to carry out an action the QUEICs will be responsible to confirm the





Start

OICensure all energy sources are identified, isolated and secured in accordance with standard or work permit procedures.

w

Finish